

# Microprocessor - 8086 Instruction Sets

The 8086 microprocessor supports 8 types of instructions –

- Data Transfer Instructions
- Arithmetic Instructions
- Bit Manipulation Instructions
- String Instructions
- Program Execution Transfer Instructions (Branch & Loop Instructions)
- Processor Control Instructions
- Iteration Control Instructions
- Interrupt Instructions

Let us now discuss these instruction sets in detail.

## Data Transfer Instructions

These instructions are used to transfer the data from the source operand to the destination operand. Following are the list of instructions under this group –

### Instruction to transfer a word

- **MOV** – Used to copy the byte or word from the provided source to the provided destination.
- **PPUSH** – Used to put a word at the top of the stack.
- **POP** – Used to get a word from the top of the stack to the provided location.
- **PUSHA** – Used to put all the registers into the stack.
- **POPA** – Used to get words from the stack to all registers.
- **XCHG** – Used to exchange the data from two locations.
- **XLAT** – Used to translate a byte in AL using a table in the memory.

### Instructions for input and output port transfer

- **IN** – Used to read a byte or word from the provided port to the accumulator.
- **OUT** – Used to send out a byte or word from the accumulator to the provided port.

### Instructions to transfer the address

- **LEA** – Used to load the address of operand into the provided register.
- **LDS** – Used to load DS register and other provided register from the memory
- **LES** – Used to load ES register and other provided register from the memory.

## Instructions to transfer flag registers

- **LAHF** – Used to load AH with the low byte of the flag register.
- **SAHF** – Used to store AH register to low byte of the flag register.
- **PUSHF** – Used to copy the flag register at the top of the stack.
- **POPF** – Used to copy a word at the top of the stack to the flag register.

## Arithmetic Instructions

These instructions are used to perform arithmetic operations like addition, subtraction, multiplication, division, etc.

Following is the list of instructions under this group –

### Instructions to perform addition

- **ADD** – Used to add the provided byte to byte/word to word.
- **ADC** – Used to add with carry.
- **INC** – Used to increment the provided byte/word by 1.
- **AAA** – Used to adjust ASCII after addition.
- **DAA** – Used to adjust the decimal after the addition/subtraction operation.

### Instructions to perform subtraction

- **SUB** – Used to subtract the byte from byte/word from word.
- **SBB** – Used to perform subtraction with borrow.
- **DEC** – Used to decrement the provided byte/word by 1.
- **NPG** – Used to negate each bit of the provided byte/word and add 1/2's complement.
- **CMP** – Used to compare 2 provided byte/word.
- **AAS** – Used to adjust ASCII codes after subtraction.
- **DAS** – Used to adjust decimal after subtraction.

### Instruction to perform multiplication

- **MUL** – Used to multiply unsigned byte by byte/word by word.
- **IMUL** – Used to multiply signed byte by byte/word by word.
- **AAM** – Used to adjust ASCII codes after multiplication.

### Instructions to perform division

- **DIV** – Used to divide the unsigned word by byte or unsigned double word by word.

- **IDIV** – Used to divide the signed word by byte or signed double word by word.
- **AAD** – Used to adjust ASCII codes after division.
- **CBW** – Used to fill the upper byte of the word with the copies of sign bit of the lower byte.
- **CWD** – Used to fill the upper word of the double word with the sign bit of the lower word.

## Bit Manipulation Instructions

These instructions are used to perform operations where data bits are involved, i.e. operations like logical, shift, etc.

Following is the list of instructions under this group –

### Instructions to perform logical operation

- **NOT** – Used to invert each bit of a byte or word.
- **AND** – Used for adding each bit in a byte/word with the corresponding bit in another byte/word.
- **OR** – Used to multiply each bit in a byte/word with the corresponding bit in another byte/word.
- **XOR** – Used to perform Exclusive-OR operation over each bit in a byte/word with the corresponding bit in another byte/word.
- **TEST** – Used to add operands to update flags, without affecting operands.

### Instructions to perform shift operations

- **SHL/SAL** – Used to shift bits of a byte/word towards left and put zero(S) in LSBs.
- **SHR** – Used to shift bits of a byte/word towards the right and put zero(S) in MSBs.
- **SAR** – Used to shift bits of a byte/word towards the right and copy the old MSB into the new MSB.

### Instructions to perform rotate operations

- **ROL** – Used to rotate bits of byte/word towards the left, i.e. MSB to LSB and to Carry Flag [CF].
- **ROR** – Used to rotate bits of byte/word towards the right, i.e. LSB to MSB and to Carry Flag [CF].
- **RCR** – Used to rotate bits of byte/word towards the right, i.e. LSB to CF and CF to MSB.
- **RCL** – Used to rotate bits of byte/word towards the left, i.e. MSB to CF and CF to LSB.

## String Instructions

String is a group of bytes/words and their memory is always allocated in a sequential order.

Following is the list of instructions under this group –

- **REP** – Used to repeat the given instruction till  $CX \neq 0$ .
- **REPE/REPZ** – Used to repeat the given instruction until  $CX = 0$  or zero flag  $ZF = 1$ .

- **REPNE/REPZ** – Used to repeat the given instruction until CX = 0 or zero flag ZF = 1.
- **MOVS/MOVS/MOVSW** – Used to move the byte/word from one string to another.
- **COMS/COMP/COMPSW** – Used to compare two string bytes/words.
- **INS/INSB/INSW** – Used as an input string/byte/word from the I/O port to the provided memory location.
- **OUTS/OUTSB/OUTSW** – Used as an output string/byte/word from the provided memory location to the I/O port.
- **SCAS/SCASB/SCASW** – Used to scan a string and compare its byte with a byte in AL or string word with a word in AX.
- **LODS/LODSB/LODSW** – Used to store the string byte into AL or string word into AX.

## Program Execution Transfer Instructions (Branch and Loop Instructions)

These instructions are used to transfer/branch the instructions during an execution. It includes the following instructions –

Instructions to transfer the instruction during an execution without any condition –

- **CALL** – Used to call a procedure and save their return address to the stack.
- **RET** – Used to return from the procedure to the main program.
- **JMP** – Used to jump to the provided address to proceed to the next instruction.

Instructions to transfer the instruction during an execution with some conditions –

- **JA/JNBE** – Used to jump if above/not below/equal instruction satisfies.
- **JAE/JNB** – Used to jump if above/not below instruction satisfies.
- **JBE/JNA** – Used to jump if below/equal/ not above instruction satisfies.
- **JC** – Used to jump if carry flag CF = 1
- **JE/JZ** – Used to jump if equal/zero flag ZF = 1
- **JG/JNLE** – Used to jump if greater/not less than/equal instruction satisfies.
- **JGE/JNL** – Used to jump if greater than/equal/not less than instruction satisfies.
- **JL/JNGE** – Used to jump if less than/not greater than/equal instruction satisfies.
- **JLE/JNG** – Used to jump if less than/equal/if not greater than instruction satisfies.
- **JNC** – Used to jump if no carry flag (CF = 0)
- **JNE/JNZ** – Used to jump if not equal/zero flag ZF = 0
- **JNO** – Used to jump if no overflow flag OF = 0
- **JNP/JPO** – Used to jump if not parity/parity odd PF = 0
- **JNS** – Used to jump if not sign SF = 0
- **JO** – Used to jump if overflow flag OF = 1

- **JP/JPE** – Used to jump if parity/parity even PF = 1
- **JS** – Used to jump if sign flag SF = 1

## Processor Control Instructions

These instructions are used to control the processor action by setting/resetting the flag values.

Following are the instructions under this group –

- **STC** – Used to set carry flag CF to 1
- **CLC** – Used to clear/reset carry flag CF to 0
- **CMC** – Used to put complement at the state of carry flag CF.
- **STD** – Used to set the direction flag DF to 1
- **CLD** – Used to clear/reset the direction flag DF to 0
- **STI** – Used to set the interrupt enable flag to 1, i.e., enable INTR input.
- **CLI** – Used to clear the interrupt enable flag to 0, i.e., disable INTR input.

## Iteration Control Instructions

These instructions are used to execute the given instructions for number of times. Following is the list of instructions under this group –

- **LOOP** – Used to loop a group of instructions until the condition satisfies, i.e., CX = 0
- **LOOPE/LOOPZ** – Used to loop a group of instructions till it satisfies ZF = 1 & CX = 0
- **LOOPNE/LOOPNZ** – Used to loop a group of instructions till it satisfies ZF = 0 & CX = 0
- **JCXZ** – Used to jump to the provided address if CX = 0

## Interrupt Instructions

These instructions are used to call the interrupt during program execution.

- **INT** – Used to interrupt the program during execution and calling service specified.
- **INTO** – Used to interrupt the program during execution if OF = 1
- **IRET** – Used to return from interrupt service to the main program